WALL PROFILE INSTALLATION GUIDE





Carcasses are mounted on the wall at least 40 cm aparts.



Mounting to the carcass is carried out by driving glass nails through the profile gaps.



The nail driving process is continued downwards on the carcasses.



The visible heads of the nailed nails are cut with the help of pliers.



Then it is entered into the profile with the help of a hammer. Or instead of this whole process, a headless nail gun can be used.



agt.com.tr

Merkez | Head Office

Organize Sanayi Bölgesi 3. Kısım, 35. Cadde, 07190 Döşemealtı, Antalya, Türkiye Tel: +90 242 249 17 17 Fax: +90 242 249 17 27

İstanbul Ofis | Istanbul Office

Kısıklı Mh. Alemdağ Cad. No: 36 34693 Çamlıca, İstanbul, Türkiye Tel: +90 216 344 82 48 Fax: +90 216 316 82 48